


Bosch Climate 5000 Series **Single Zone Outdoor Unit**

BMS500-AAS024-1CSXHB | BMS500-AAS030-1CSXRB | BMS500-AAS036-1CSXRB



BOSCH

Pos.	Description	Qty	BMS500-AAS024-1CSXHB	BMS500-AAS030-1CSXRB	BMS500-AAS036-1CSXRB	Recommended Stock	Remarks
1	Left side plate assembly of cabinet	1.0	7-738-005-666	7-738-005-666	7-738-005-666		
1.1	Small handle	1.0	7-738-005-667	7-738-005-667	7-738-005-667		
2	Condenser	1.0	8-733-953-860	8-733-953-824	8-733-953-836	✓	
3	Pipe temperature sensor	1.0	7-738-005-560	7-738-005-560	7-738-005-560	✓	
4	Rear right clapboard assembly	1.0	7-738-005-670	7-738-005-670	7-738-005-670		
5	Handle	1.0	8-733-953-825	8-733-953-825	8-733-953-825		
6	Water collector	1.0	7-738-005-672	7-738-005-672	7-738-005-672		
7	Front right clapboard assembly	1.0	7-738-005-673	7-738-005-673	7-738-005-673		
7.1	Handle	1.0	7-738-005-674	7-738-005-674	7-738-005-674		
9	Chassis assembly	1.0	7-738-005-675	7-738-005-675	7-738-005-675		
10	Front panel	1.0	7-738-005-676	7-738-005-676	7-738-005-676		
12	Axial flow fan	1.0	7-738-005-678	7-738-005-678	7-738-005-678	✓	
13	Brushless DC Motor	1.0	7-738-005-679	7-738-005-679	7-738-005-679	✓	
14	Supporter subassembly of fan motor	1.0	7-738-005-680	7-738-005-680	7-738-005-680		
15	Accumulator cylinder	1.0	N/A	N/A	8-733-945-616	✓	
16	Partition board assembly	1.0	7-738-005-681	7-738-005-681	7-738-005-681		
18	Top cover assembly	1.0	7-738-005-682	7-738-005-682	7-738-005-682		
19	Electronic control box subassembly	1.0	8-733-953-861	8-733-953-826	8-733-953-837		
19.1	Electronic installing box subassembly	1.0	8-733-945-552	8-733-945-552	8-733-945-552		
19.2	Outdoor main control board	1.0	8-733-953-862	8-733-953-827	8-733-953-838	✓	
19.4	Electronic installing box subassembly	1.0	8-733-945-551	8-733-945-551	8-733-945-551		
19.7	Inverter module	1.0	8-733-953-828	8-733-953-828	8-733-953-828	✓	
20	Terminal board subassembly	1.0	7-738-005-687	7-738-005-687	7-738-005-687	✓	
20.1	Terminal	1.0	7-738-005-688	7-738-005-688	7-738-005-688		
20.2	Terminal board	1.0	7-738-005-689	7-738-005-689	7-738-005-689		
21	Reversing valve assembly	1.0	8-733-953-863	8-733-953-829	8-733-953-839	✓	
21.1	Gas valve	1.0	7-738-005-691	7-738-005-691	7-738-005-691		
21.2	4-way valve	1.0	7-738-005-692	7-738-005-692	7-738-005-692		
21.4	Suction pipe	1.0	8-733-953-830	8-733-953-830	8-733-953-840		
21.5	Discharge pipe	1.0	8-733-953-831	8-733-953-831	8-733-953-841		
22	EEV assembly	1.0	8-733-953-832	8-733-953-832	8-733-953-842	✓	
22.1	Gas valve	1.0	7-738-005-574	7-738-005-574	7-738-005-574		
22.2	Electronic expansion valve body	1.0	7-738-005-694	7-738-005-694	8-733-953-843		
22.3	Valve plate	1.0	7-738-005-695	7-738-005-695	7-738-005-695		
24	Copper nut	1.0	8-733-953-586	8-733-953-586	8-733-953-586		
24	Copper nut	1.0	8-733-953-585	8-733-953-585	8-733-953-585		
25	Rear net	1.0	7-738-005-696	7-738-005-696	7-738-005-696	✓	
26	DC Inverter rotary compressor	1.0	7-738-005-697	8-733-953-833	8-733-953-833	✓	
27	PFC inductor	1.0	8-733-953-834	8-733-953-834	8-733-953-834	✓	
29	Discharge temperature sensor	1.0	7-738-005-699	7-738-005-699	7-738-005-699	✓	
30	Room temperature sensor	1.0	8-733-953-835	8-733-953-835	8-733-953-835	✓	
31	Suction pipe assembly	1.0	N/A	N/A	8-733-953-844	✓	
31.1	Pressure switch	1.0	N/A	N/A	8-733-945-643		
32	Discharge pipe assembly	1.0	N/A	N/A	8-733-953-845		
32.1	Pressure switch	1.0	N/A	N/A	8-733-953-846		
38	Crankcase electric heater	1.0	7-738-005-728	7-738-005-728	7-738-005-728	✓	
39	Electric heating tube	1.0	7-738-005-724	7-738-005-724	7-738-005-724	✓	
99	Compressor wire subassembly	1.0	7-738-005-700	7-738-005-700	7-738-005-700	✓	
BMS500-AAS024-1CSXHB BMS500-AAS030-1CSXRB BMS500-AAS036-1CSXRB							